

1. Remove the existing roof underlayment & shingles, existing roof decking, drip edge and all unsupported eaves/overhang around the home on all sides. Install new 2x6 fascia gutter boards and gable fascia boards directly to the home and wrap with white aluminum trim coil. Include any new decking, underlayment, shingles and new drip edge needed. New white drip edge is to be installed around the home. Any new roofing needed is to match and tie into the existing roof as close as possible. The existing front porch ceiling is not to be disturbed. Include any siding, J channel, flashing and/or trim that may be needed to complete.
2. After new gutter boards and aluminum is installed, install new white 6-inch seamless gutters on the home with all new white downspouts. The new gutters are to be hung using hidden hangers. The new downspouts are to empty onto new concrete splash blocks and divert the rainwater away from the foundation. Include any materials and labor needed to complete.
3. Install new black vinyl weather stripping to the existing front door and jamb to seal from outside air. Install a new full view black security storm door to the existing front door. The new storm door is to match the existing as close as possible. Allow \$350 for the new storm door. Include all materials and labor to complete.

1010 Bellemeade Ave., Evansville, IN 47714

Scope of Service - Photos





1010 Bellemeade Ave., Evansville, IN 47714

Scope of Service - Photos

Bad gutters. 1010  
Bellemeade. 5-20-25





1010 Bellemeade Ave., Evansville, IN 47714

Scope of Service - Photos

Bad gutter. 1010 Bellemeade.  
5-20-25





1010 Bellemeade Ave., Evansville, IN 47714

Scope of Service - Photos



Damaged soffit & fascia.  
1010 Bellemeade. 5-20-25



1010 Bellemeade Ave., Evansville, IN 47714

Scope of Service - Photos



Front storm door. 1010 Bellemeade.  
5-20-25



1010 Bellemeade Ave., Evansville, IN 47714

Scope of Service - Photos

